

Scope of application

This document is to make quick and faster installation guide for jumper cable with weatherproof boot, the jumper cable can be 1/2" super flexible, 1/2" flexible, 1/4" super flexible, and the connector can use DIN, N, 4.3/10, Nex10, straight and angled.

Tools recommend

Torque wrench, non-slip gloves.

Progress for reference (DIN male for example)

	  
1, Jumper appearance inspect, be sure there is no burr, damage on the cable, connector and the weatherproof boot.	2, Match the jumper connector to the antenna flange, use the torque wrench to fix the connector Coupling torque recommend: 25 to 30N.m for DIN connector, 5-8N.m for 4.3-10 connector, 0.7-1.1N.m for N connector.
  	
3, Push the weatherproof boot over the connector, till it is full cover the connection	4, The other port with the same progress, fix the connector, then assembled the weatherproof boot